



Article	Part No.	Description
BOLT	11233-06183	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT(W/WASHER)	11254-06203	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
BOLT	11290-06121	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 96)
BOLT	11290-06253	2900 CC; AUTO TRANSFER(ELECTRIC), EMISSION(EC 2000)
BOLT	11290-08253	2900 CC; AUTO TRANSFER(ELECTRONIC), EMISSION(EC 2000)
BOLT-WASHER ASSY	11293-06143	2900 CC; EMISSION(EC 2000)
BOLT	11293-06303	2900 CC; AUTO TRANSFER(ELECTRIC), EMISSION(EC 2000)
BOLT	11293-08303	2900 CC; AUTO TRANSFER(ELECTRONIC), EMISSION(EC 2000)
BOLT	11302-06303	D4BH(4D56 TCI), LHD; FUEL INJ-ELECTRONIC TYPE
BOLT	11302-06353	D4BH(4D56 TCI), LHD; FUEL INJ-ELECTRONIC TYPE
BOLT	11401-10203	3500 CC

BOLT	11403-06163	3500 CC; UNLEADED PACKAGE
BOLT	11403-06123	3500 CC
BOLT	11403-06183	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
BOLT	11403-08123	3500 CC
BOLT	11403-06107K	2900 CC, T/C INTER COOLER, 4 SPEED AT 4WD; FUEL INJ-ELECTRONIC TYPE
	11403-06107K	2900 CC; FUEL INJ-ELECTRONIC TYPE
	11403-06103	3500 CC
	11403-06103	D4BH(4D56 TCI); EMISSION(EC 96), FUEL INJ-ELECTRONIC TYPE
NUT-FLANGE	13385-06003	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
NUT-FLANGE	13395-06003	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRIC)
	13395-06003	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRONIC)
	13395-06001	3500 CC
	13395-06003	3500 CC, MPI-DOHC, 4 SPEED AT 4WD; EMISSION(EC 2000), UNLEADED PACKAGE
	13395-06003	3500 CC; EVAP. GAS CONTROL, EMISSION(EC 2000), UNLEADED PACKAGE
	13395-06003	3500 CC; UNLEADED PACKAGE
	13395-06001	D4BH(4D56 TCI); EMISSION(EC 96), FUEL INJ-ELECTRONIC TYPE
	13395-06001	D4BH(4D56 TCI); EMISSION(EC 96), FUEL INJ-ELECTRONIC TYPE, IMMOBILIZER
NUT-FLANGE	13395-08003	3500 CC; UNLEADED PACKAGE
CLIP	14890-00609	3500 CC
STRAP	17993-10000	LHD, 2900 CC, D4BH(4D56 TCI)
BAND-CABLE	17998-15207	2900 CC, RHD; EMISSION(EC 2000)
SENSOR-IGNITION FAILURE	27370-38010	3500 CC, MPI-DOHC, 4 SPEED AT 4WD; EMISSION(EC 2000), UNLEADED PACKAGE
	27370-38000	3500 CC, MPI-DOHC, 4 SPEED AT 4WD; EMISSION(EC 2000), UNLEADED PACKAGE
	27370-38000	3500 CC; EVAP. GAS CONTROL, EMISSION(EC 2000), UNLEADED PACKAGE
	27370-38010	3500 CC; EVAP. GAS CONTROL, EMISSION(EC 2000), UNLEADED PACKAGE
	27370-38010	3500 CC; UNLEADED PACKAGE
	27370-38000	3500 CC; UNLEADED PACKAGE
TANK-VACUUM	28307-35560	3500 CC; UNLEADED PACKAGE
HOSE	28352-39070	3500 CC; UNLEADED PACKAGE
HOSE	28352-39130	3500 CC; UNLEADED PACKAGE
HOSE(BLACK)	28352-39080	3500 CC; UNLEADED PACKAGE
HOSE(BLACK)	28352-39190	3500 CC; UNLEADED PACKAGE
HOSE(BLACK)	28352-39350	3500 CC; UNLEADED PACKAGE
HOSE(BLACK)	28352-39880	3500 CC; UNLEADED PACKAGE
HOSE(RED)	28352-39180	3500 CC; UNLEADED PACKAGE
PIPE ASSY-VACUUM	28360-39840	3500 CC, MPI-DOHC, 4 SPEED AT 4WD; EMISSION(EC 2000), UNLEADED PACKAGE
	28360-39820	3500 CC, MPI-DOHC, 4 SPEED AT 4WD; EMISSION(EC 2000), UNLEADED PACKAGE

	28360-39820	3500 CC; EVAP. GAS CONTROL, EMISSION(EC 2000), UNLEADED PACKAGE
	28360-39840	3500 CC; EVAP. GAS CONTROL, EMISSION(EC 2000), UNLEADED PACKAGE
	28360-39840	3500 CC; UNLEADED PACKAGE
	28360-39820	3500 CC; UNLEADED PACKAGE
TERMINAL-VACUUM	HQ803848	D4BH(4D56 TCI), LHD; FUEL INJ-ELECTRONIC TYPE
CLAMP-HOSE	28366-21300	3500 CC; UNLEADED PACKAGE
JOINT-VACUUM HOSE	HQ803847	D4BH(4D56 TCI), LHD; FUEL INJ-ELECTRONIC TYPE
BRKT-RUBBER	35121-27050	2900 CC; EMISSION(EC 2000)
ECU-ECD	39100-42450	D4BH(4D56 TCI); EMISSION(EC 96), FUEL INJ-ELECTRONIC TYPE
	39100-42440	D4BH(4D56 TCI); EMISSION(EC 96), FUEL INJ-ELECTRONIC TYPE, IMMOBILIZER
ELECTRONIC CONTROL UNIT	39110-39865	3500 CC, LHD; EMISSION(EC 2000), IMMOBILIZER, UNLEADED PACKAGE
	39110-39885	3500 CC, LHD; EMISSION(EC 2000), UNLEADED PACKAGE
	39110-39835	3500 CC, LHD; UNLEADED PACKAGE
	39110-39865	3500 CC, MPI-DOHC, 4 SPEED AT 4WD, LHD; EMISSION(EC 2005), IMMOBILIZER, UNLEADED PACKAGE
	39110-39825	3500 CC, MPI-DOHC, 4 SPEED AT 4WD, LHD; IMMOBILIZER, UNLEADED PACKAGE
	39110-39865	3500 CC, MPI-DOHC, 4 SPEED AT 4WD, LHD; IMMOBILIZER, UNLEADED PACKAGE
	39110-39825	3500 CC, MPI-DOHC, 5 SPEED MT 4WD, LHD; IMMOBILIZER, UNLEADED PACKAGE
RELAY ASSY-POWER	39160-39300	3500 CC
	39160-39100	3500 CC
RELAY-POWER	39160-39350	3500 CC
	39160-24550	3500 CC
	39160-39150	3500 CC
SENSOR-CRANKSHAFT POSITION	39650-42150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD; EMISSION(EC 96), FUEL INJ-ELECTRONIC TYPE
	39650-42140	D4BH(4D56 TCI), T/C INTER COOLER, 5 SPEED MT 4WD; EMISSION(EC 96), FUEL INJ-ELECTRONIC TYPE
CLIP-CONNECTOR	39181-42000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 96)
SENSOR ASSY-BOOST	39200-42020	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
SENSOR ASSY-MAP	39300-38100	3500 CC, MPI-DOHC, 4 SPEED AT 4WD; EMISSION(EC 2000), UNLEADED PACKAGE
	39300-38200	3500 CC, MPI-DOHC, 4 SPEED AT 4WD; EMISSION(EC 2000), UNLEADED PACKAGE
	39300-38200	3500 CC; EVAP. GAS CONTROL, EMISSION(EC 2000), UNLEADED PACKAGE
	39300-38100	3500 CC; EVAP. GAS CONTROL, EMISSION(EC 2000), UNLEADED PACKAGE
SENSOR-CAMSHAFT POSITION(TDC)	39300-4X300	2900 CC; FUEL INJ-ELECTRONIC TYPE
SENSOR-CRANKSHAFT ANGLE	39310-39800	3500 CC

SENSOR-CAMSHAFT POSITION	39318-39800	3500 CC
BRACKET-CPS	39381-4X900	2900 CC; FUEL INJ-ELECTRONIC TYPE
BOLT	39313-33341	3500 CC
SENSOR-KNOCK	39510-39810	3500 CC
BRACKET-KNOCK SENSOR	39321-35510	3500 CC
VALVE ASSY-SOLENOID	35120-27050	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRIC)
	35120-27050	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRONIC)
	HQ803855	D4BH(4D56 TCI), LHD; EMISSION(EC 96), FUEL INJ-ELECTRONIC TYPE
	HQ803855	D4BH(4D56 TCI), T/C INTER COOLER, 5 SPEED MT 4WD, LHD; FUEL INJ-ELECTRONIC TYPE
VALVE ASSY-EGR SOL	39400-H1000	D4BH(4D56 TCI), LHD; FUEL INJ-ELECTRONIC TYPE
VALVE ASSY- SOLENOID	HQ803856	D4BH(4D56 TCI), LHD; FUEL INJ-ELECTRONIC TYPE
MTG RUBBER-SOL.VALVE	39413-4X400	2900 CC; EMISSION(EC 2000)
TERMINAL-VACUUM	39413-27000	2900 CC; AUTO TRANSFER(ELECTRIC), EMISSION(EC 2000)
HOSE ASSY-EGR VACUUM	39430-4X430	2900 CC; AUTO TRANSFER(ELECTRIC), EMISSION(EC 2000)
VALVE-PURGE CONTROL SOLENOID	39460-38650	3500 CC; UNLEADED PACKAGE
VALVE-SOLENOID	39460-26500	3500 CC; UNLEADED PACKAGE
WIRING-INJECTOR	39610-39850	3500 CC
	39610-39800	3500 CC
HARNESS-IGNITION COIL	39610-39400	3500 CC
BRKT-CONNECTOR	39611-39830	3500 CC
	39611-39900	3500 CC
VALVE-CHECK(DSL)	51201-H1600	2900 CC; AUTO TRANSFER(ELECTRIC), EMISSION(EC 2000)
HOSE(BLACK )	17905-39999	3500 CC; EMISSION(EC 2000), UNLEADED PACKAGE
HOSE(GREEN )	17905-39999JA	3500 CC; UNLEADED PACKAGE
ELECTRONIC CONTROL UNIT(ENG)	39101-4X750	2900 CC, LHD; EMISSION(EC 2000), FUEL INJ-ELECTRONIC TYPE
	39112-4X510	2900 CC; EMISSION(EC 2000), FUEL INJ-ELECTRONIC TYPE
	39112-4X510	2900 CC; EMISSION(EC 2000), FUEL INJ-ELECTRONIC TYPE, IMMOBILIZER
	39101-4X740	2900 CC; EMISSION(EC 2000), FUEL INJ-ELECTRONIC TYPE, IMMOBILIZER
SENSOR-KNOCK	39250-4X000	2900 CC; FUEL INJ-ELECTRONIC TYPE
BRKT-KNOCK SENSOR	39281-4X000	2900 CC; FUEL INJ-ELECTRONIC TYPE
BRKT-EGR SOLENOID VALVE	39420-4X510	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRIC)
	39420-4X510	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRIC)
	39420-4X520	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRONIC)
	39420-4X520	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRONIC)
BRKT- SOLENOID VALVE	39420-4X730	2900 CC; EMISSION(EC 2000)
VALVE - EGR SOLENOID	39400-4X120	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRIC)
	39400-4X100	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRIC)
	39400-4X100	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRONIC)
	39400-4X120	2900 CC; EMISSION(EC 2000), AUTO TRANSFER(ELECTRONIC)

VALVE - SOLENOID	39400-4X700	2900 CC; EMISSION(EC 2000)
HOSE-VACUUM	39472-4X390	2900 CC; EMISSION(EC 2000)
HOSE-VACUUM	39472-4X540	2900 CC; AUTO TRANSFER(ELECTRIC), EMISSION(EC 2000)
HOSE-VACUUM	39472-4X530	2900 CC; AUTO TRANSFER(ELECTRIC), EMISSION(EC 2000)
HOSE-VACUUM	39472-4X520	2900 CC; AUTO TRANSFER(ELECTRIC), EMISSION(EC 2000)
HOSE-VACUUM	39472-4X510	2900 CC; EMISSION(EC 2000)
PIPE & HOSE ASSY-VACUUM	39491-4X700	2900 CC, RHD; EMISSION(EC 2000)
SENSOR-CRANKSHAFT POSITION	39600-4X000	2900 CC, T/C INTER COOLER, 4 SPEED AT 4WD; FUEL INJ-ELECTRONIC TYPE
	39600-4X000	2900 CC, T/C INTER COOLER, 4 SPEED AT 4WD; FUEL INJ-ELECTRONIC TYPE
	39600-4X100	2900 CC, T/C INTER COOLER, 5 SPEED MT 4WD; FUEL INJ-ELECTRONIC TYPE
BRKT-C.P SENSOR CONNECTOR	39650-4X000	2900 CC, T/C INTER COOLER, 5 SPEED MT 4WD; FUEL INJ-ELECTRONIC TYPE
BRKT-C.P SENSOR CONNECTOR	39650-4X100	2900 CC, T/C INTER COOLER, 5 SPEED MT 4WD; FUEL INJ-ELECTRONIC TYPE
WASHER & NUT	K9090-60602B	2900 CC; AUTO TRANSFER(ELECTRIC), EMISSION(EC 2000)
BOLT	K9979-60830	2900 CC; FUEL INJ-ELECTRONIC TYPE
BOLT	K9979-40612	2900 CC; FUEL INJ-ELECTRONIC TYPE
BOLT	K9979-40614	2900 CC, T/C INTER COOLER, 5 SPEED MT 4WD; FUEL INJ-ELECTRONIC TYPE
BOLT	K9979-40616	2900 CC, T/C INTER COOLER, 4 SPEED AT 4WD; FUEL INJ-ELECTRONIC TYPE