



Article	Part No.	Description
BOLT-I/COOLER	0K551-13707	2900 CC; EMISSION(EC 2000)
JOINT PIPE ASSY-OUTLET	0K88R-13510	2900 CC; EMISSION(EC 2000)
PIPE ASSY-W/IN,T/C	0K88R-13530	2900 CC; EMISSION(EC 2000)
PIPE ASSY-W/OUT ,T/C	0K88R-13540	2900 CC; EMISSION(EC 2000)
BOLT	11233-06163	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT	11233-08163	2900 CC
BOLT	11233-08183	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT(W/WASHER)	11254-08353	2900 CC
BOLT	11400-06103	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT	11403-06163	2900 CC
BOLT	11403-06123	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT	11403-08123	2900 CC; EMISSION(EC 2000)
BOLT-FLANGE(8*65)	11403-08143	2900 CC; EMISSION(EC 2000)
BOLT	11405-08163	2900 CC
SCREW-MACHINE	12291-05163	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE

PIN	14305-06001	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
CLAMP-HOSE	14720-23008	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT-EYE JOINT	15407-10201	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	15407-10203	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
GASKET(10)	17512-10000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STUD-EXI.MANIFOLD	0K551-10266A	2900 CC; EMISSION(EC 2000)
PROTECTOR-HEAT	28264-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
PROTECTOR-HEAT "C"	28263-42880	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-AIR CLEANER INLET NO.2	28162-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
CLAMP-HOSE	28185-22010	2900 CC; FUEL INJ-ELECTRONIC TYPE
COOLER ASSY-INTER	28190-4X400	2900 CC; EMISSION(EC 2000)
	28190-4X700	2900 CC; FUEL INJ-ELECTRONIC TYPE
	28211-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28211-H1302	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
TUBE-BRANCH	HR140160A	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BRKT ASSY-I/C	28210-H1302	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28210-H1303	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
TUBE-BRANCH	28215-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
COVER-INTERCOOLER	28213-H1301	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
FAN & MOTOR ASSY	HR805800	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
TURBOCHARGER ASSY	28200-4X400	2900 CC; EMISSION(EC 2000)
	28200-4A210	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BLOWER ASSY	28220-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
NUT-LOCK	28256-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
COVER ASSY-ENGINE	28235-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
PIPE ASSY-OIL DRAIN	28240-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28240-4B150	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT-S/W & L P/W ASSY	28241-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28241-H1301	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28241-H1301	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
CLAMP-HOSE	28244-42881	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-OIL	28245-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
PIPE-OIL RETURN	28246-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
GASKET-OIL RETURN PIPE	28247-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28247-4A150	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
ACTUATOR-TURBO CHARGER	28248-4A200	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-BOOST	28249-42880	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STUD	28257-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STAY	28265-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
FITTING ASSY-EXHAUST	28280-42540	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28280-42541	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
COVER-EXHAUST FITTING	28283-4B150	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
GASKET-TURBOCHARGER INLET	28250-42540	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE

BOLT	28285-42540	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
GASKET-TURBOCHARGER OUTLET	28255-42540	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
CLAMP-HOSE	28292-41401	2900 CC; EMISSION(EC 2000)
	28292-42000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
CLIP-HOSE	28292-27020	2900 CC
CLIP-HOSE	28292-27030	2900 CC
BOLT	28528-22000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STUD	28532-42000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
WASHER-PLAIN	28259-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STAY-T/CHARGER	28593-4X700	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
HOSE-AIR A-1	28230-H1000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-AIR "B"	28233-H1302	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28233-H1303	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-AIR "C"	28232-H1301	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28232-H1302	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT	29217-23600	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
FAN SHROUD ASSY	HR140140	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STUD	KKY01-13456	2900 CC; EMISSION(EC 2000)
STUD	0K551-13455A	2900 CC; EMISSION(EC 2000)
STUD	K9985-10635B	2900 CC; EMISSION(EC 2000)
STUD	K9985-10670	2900 CC; EMISSION(EC 2000)
INSULATOR ASSY-HEAT	0K88R-13370	2900 CC; EMISSION(EC 2000)
NUT	0K710-13461	2900 CC; EMISSION(EC 2000)
NUT	0JF03-13465	2900 CC; EMISSION(EC 2000)
STAY-T/CHARGER	0K88R-13467	2900 CC; EMISSION(EC 2000)
CLIP	0K551-13532B	2900 CC; EMISSION(EC 2000)
BOLT-CONNECTOR	0K551-13545A	2900 CC; EMISSION(EC 2000)
ELBOW-T/C	0K88R-13701	2900 CC; EMISSION(EC 2000)
GASKET-T/C ELBOW	0K88R-13702	2900 CC; EMISSION(EC 2000)
PIPE-OIL	0K551-14290	2900 CC; EMISSION(EC 2000)
GASKET	0K551-14293	2900 CC; EMISSION(EC 2000)
BOLT-CONNECTOR	0K551-14458A	2900 CC; EMISSION(EC 2000)
BOLT	0RF10-14458B	2900 CC; EMISSION(EC 2000)
PACKING	K9956-21000	2900 CC; EMISSION(EC 2000)
PACKING	K9956-21400	2900 CC; EMISSION(EC 2000)
HOSE-I/COOLER OUTLET	28163-4X700	2900 CC; FUEL INJ-ELECTRONIC TYPE
HOSE-I/COOLER INLET	28162-4X100	2900 CC
BRKT ASSY-I/C RR.1	0K88R-13570	2900 CC
BRKT ASSY-I/C RR.2	0K88R-13580	2900 CC
BRKT ASSY-I/C FRT	28193-4X440	2900 CC
TURBOCHARGER	28201-4X700	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
COVER-ENGINE	28240-4X400	2900 CC
HOSE-OIL OUTLET	28246-4X100	2900 CC; EMISSION(EC 2000)

	28246-4X102	2900 CC; EMISSION(EC 2000), FUEL INJ-ELECTRONIC TYPE
	28246-4X101	2900 CC; EMISSION(EC 2000), FUEL INJ-ELECTRONIC TYPE
PIPE-OIL IN.T/C	28247-4X400	2900 CC; EMISSION(EC 2000)
	28247-4X700	2900 CC; EMISSION(EC 2000), FUEL INJ-ELECTRONIC TYPE
GASKET-TURBOCHARGER	0K551-13470A	2900 CC; EMISSION(EC 2000)
GASKET-EGR PIPE	0K551-13490B	2900 CC; EMISSION(EC 2000)
CLIP-HOSE	0K553-32C22	2900 CC; EMISSION(EC 2000)
BOLT	K9979-40670B	2900 CC; EMISSION(EC 2000)
CONNECTOR	K9936-71014	2900 CC; EMISSION(EC 2000)
BOLT	K9079-60612B	2900 CC; EMISSION(EC 2000)
CLIP	K9928-31400	2900 CC; EMISSION(EC 2000)
CLIP-HOSE	K9928-31400B	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
CLIP-HOSE	K9928-32000	2900 CC; EMISSION(EC 2000)
BOLT-FLANGE	K9978-40612B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60616B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60620B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60810B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60812B	2900 CC; EMISSION(EC 2000)
BOLT-FLANGE	K9979-60816B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-61216B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60635B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60820B	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
CLAMP-HOSE	K9928-00650	2900 CC
NUT-FLANGE	K9994-00600B	2900 CC; EMISSION(EC 2000)

BOLT-I/COOLER 0K551-13707 2900 CC; EMISSION(EC 2000)

JOINT PIPE ASSY-OUTLET 0K88R-13510 2900 CC; EMISSION(EC 2000)

PIPE ASSY-W/IN,T/C 0K88R-13530 2900 CC; EMISSION(EC 2000)

PIPE ASSY-W/OUT ,T/C 0K88R-13540 2900 CC; EMISSION(EC 2000)

BOLT 11233-06163 D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE

BOLT 11233-08163 2900 CC

BOLT 11233-08183 D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE

BOLT(W/WASHER) 11254-08353 2900 CC

BOLT 11400-06103 D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE

BOLT 11403-06163 2900 CC

BOLT 11403-06123 D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE

BOLT 11403-08123 2900 CC; EMISSION(EC 2000)

BOLT-FLANGE(8*65) 11403-08143 2900 CC; EMISSION(EC 2000)

BOLT	11405-08163	2900 CC
SCREW-MACHINE	12291-05163	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
PIN	14305-06001	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
CLAMP-HOSE	14720-23008	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT-EYE JOINT	15407-10201	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	15407-10203	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
GASKET(10)	17512-10000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STUD-EXL.MANIFOLD	0K551-10266A	2900 CC; EMISSION(EC 2000)
PROTECTOR-HEAT	28264-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
PROTECTOR-HEAT "C"	28263-42880	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-AIR CLEANER INLET NO.2	28162-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
CLAMP-HOSE	28185-22010	2900 CC; FUEL INJ-ELECTRONIC TYPE
	28190-4X400	2900 CC; EMISSION(EC 2000)
	28190-4X700	2900 CC; FUEL INJ-ELECTRONIC TYPE
COOLER ASSY-INTER	28211-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28211-H1302	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
TUBE-BRANCH	HR140160A	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28210-H1302	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BRKT ASSY-I/C	28210-H1303	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28215-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
COVER-INTERCOOLER	28213-H1301	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
FAN & MOTOR ASSY	HR805800	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
TURBOCHARGER ASSY	28200-4X400	2900 CC; EMISSION(EC 2000)

	28200-4A210	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BLOWER ASSY	28220-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
NUT-LOCK	28256-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
COVER ASSY-ENGINE	28235-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
PIPE ASSY-OIL DRAIN	28240-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28240-4B150	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28241-H1300	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT-S/W & L P/W ASSY	28241-H1301	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28241-H1301	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
CLAMP-HOSE	28244-42881	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-OIL	28245-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
PIPE-OIL RETURN	28246-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
GASKET-OIL RETURN PIPE	28247-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28247-4A150	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
ACTUATOR-TURBO CHARGER	28248-4A200	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-BOOST	28249-42880	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STUD	28257-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STAY	28265-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
FITTING ASSY-EXHAUST	28280-42540	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28280-42541	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
COVER-EXHAUST FITTING	28283-4B150	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE

GASKET-TURBOCHARGER INLET	28250-42540	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT	28285-42540	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
GASKET-TURBOCHARGER OUTLET	28255-42540	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28292-41401	2900 CC; EMISSION(EC 2000)
CLAMP-HOSE	28292-42000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
CLIP-HOSE	28292-27020	2900 CC
CLIP-HOSE	28292-27030	2900 CC
BOLT	28528-22000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STUD	28532-42000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
WASHER-PLAIN	28259-42850	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STAY-T/CHARGER	28593-4X700	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
HOSE-AIR A-1	28230-H1000	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28233-H1302	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-AIR "B"	28233-H1303	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
	28232-H1301	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
HOSE-AIR "C"	28232-H1302	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
BOLT	29217-23600	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
FAN SHROUD ASSY	HR140140	D4BH(4D56 TCI); FUEL INJ-ELECTRONIC TYPE
STUD	KKY01-13456	2900 CC; EMISSION(EC 2000)
STUD	0K551-13455A	2900 CC; EMISSION(EC 2000)
STUD	K9985-10635B	2900 CC; EMISSION(EC 2000)
STUD	K9985-10670	2900 CC; EMISSION(EC 2000)
INSULATOR ASSY-HEAT	0K88R-13370	2900 CC; EMISSION(EC 2000)
NUT	0K710-13461	2900 CC; EMISSION(EC 2000)
NUT	0JF03-13465	2900 CC; EMISSION(EC 2000)

STAY-T/CHARGER	0K88R-13467	2900 CC; EMISSION(EC 2000)
CLIP	0K551-13532B	2900 CC; EMISSION(EC 2000)
BOLT-CONNECTOR	0K551-13545A	2900 CC; EMISSION(EC 2000)
ELBOW-T/C	0K88R-13701	2900 CC; EMISSION(EC 2000)
GASKET-T/C ELBOW	0K88R-13702	2900 CC; EMISSION(EC 2000)
PIPE-OIL	0K551-14290	2900 CC; EMISSION(EC 2000)
GASKET	0K551-14293	2900 CC; EMISSION(EC 2000)
BOLT-CONNECTOR	0K551-14458A	2900 CC; EMISSION(EC 2000)
BOLT	0RF10-14458B	2900 CC; EMISSION(EC 2000)
PACKING	K9956-21000	2900 CC; EMISSION(EC 2000)
PACKING	K9956-21400	2900 CC; EMISSION(EC 2000)
HOSE-I/COOLER OUTLET	28163-4X700	2900 CC; FUEL INJ-ELECTRONIC TYPE
HOSE-I/COOLER INLET	28162-4X100	2900 CC
BRKT ASSY-I/C RR.1	0K88R-13570	2900 CC
BRKT ASSY-I/C RR.2	0K88R-13580	2900 CC
BRKT ASSY-I/C FRT	28193-4X440	2900 CC
TURBOCHARGER	28201-4X700	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
COVER-ENGINE	28240-4X400	2900 CC
	28246-4X100	2900 CC; EMISSION(EC 2000)
HOSE-OIL OUTLET	28246-4X102	2900 CC; EMISSION(EC 2000), FUEL INJ- ELECTRONIC TYPE
	28246-4X101	2900 CC; EMISSION(EC 2000), FUEL INJ- ELECTRONIC TYPE
	28247-4X400	2900 CC; EMISSION(EC 2000)
PIPE-OIL IN.T/C	28247-4X700	2900 CC; EMISSION(EC 2000), FUEL INJ- ELECTRONIC TYPE
GASKET-TURBOCHARGER	0K551-13470A	2900 CC; EMISSION(EC 2000)
GASKET-EGR PIPE	0K551-13490B	2900 CC; EMISSION(EC 2000)
CLIP-HOSE	0K553-32C22	2900 CC; EMISSION(EC 2000)
BOLT	K9979-40670B	2900 CC; EMISSION(EC 2000)
CONNECTOR	K9936-71014	2900 CC; EMISSION(EC 2000)
BOLT	K9079-60612B	2900 CC; EMISSION(EC 2000)
CLIP	K9928-31400	2900 CC; EMISSION(EC 2000)
CLIP-HOSE	K9928-31400B	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
CLIP-HOSE	K9928-32000	2900 CC; EMISSION(EC 2000)
BOLT-FLANGE	K9978-40612B	2900 CC; EMISSION(EC 2000)

BOLT	K9979-60616B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60620B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60810B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60812B	2900 CC; EMISSION(EC 2000)
BOLT-FLANGE	K9979-60816B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-61216B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60635B	2900 CC; EMISSION(EC 2000)
BOLT	K9979-60820B	2900 CC; FUEL INJ-ELECTRONIC TYPE, EMISSION(EC 2000)
CLAMP-HOSE	K9928-00650	2900 CC
NUT-FLANGE	K9994-00600B	2900 CC; EMISSION(EC 2000)