



Article	Part No.	Description
BOLT(W/WASHER)	11290-06163	ALL
NUT	13100-06003	ALL
NUT	13454-10001	ALL
CLIP-HOOD LATCH	81199-33000	ALL
MOTOR & PUMP ASSY-W/S WASHER	98510-H1000	ALL
MOTOR & PUMP ASSY-W/WASHER	98520-H1000	ALL
CONNECTOR-W/SHLD WASHER	98516-21100	ALL
CLIP	98641-M2000	ALL
SPACER-W/S WASHER	98617-H1000	ALL
SEAL'G-RUBBER	98618-H1000	ALL
RESERVOIR ASSY-W/SHLD WASHER	98611-H1001	ALL
GATE ASSY-W/S WASER	98620-H1000	ALL
GROMMET-W/SHLD WASHER	98622-14200	ALL
CAP-W/SHLD WASHER RSVR	98613-H1000	LHD
NOZZLE ASSY-W/SHLD WASHER	98630-H1000	5 DR WAGON 7, MIDDLE GRADE, LHD
	98630-H1000	5 DR WAGON, MIDDLE GRADE, 2900 CC, LHD
	98630-H1100	5 DR WAGON, MIDDLE GRADE, 2900 CC, RHD
	98630-H1000	5 DR WAGON, MIDDLE GRADE, 3500 CC, LHD
	98630-H1000	5 DR WAGON, MIDDLE GRADE, D4BH(4D56 TCI), LHD
HOSE ASSY-W/SHLD WASHER	98650-H1011	5 DR WAGON 7, MIDDLE GRADE, LHD

	98650-H1010	5 DR WAGON, MIDDLE GRADE, 2900 CC
	98650-H1011	5 DR WAGON, MIDDLE GRADE, 2900 CC, 3500 CC
	98650-H1010	5 DR WAGON, MIDDLE GRADE, 3500 CC
	98650-H1010	5 DR WAGON, MIDDLE GRADE, D4BH(4D56 TCI)
	98650-H1011	5 DR WAGON, MIDDLE GRADE, D4BH(4D56 TCI)
CONNECTOR-W/SHLD WASHER	98651-29000	ALL
CONNECTOR-W/SHLD WASHER HOSE	98652-37100	ALL
ELBOW CONNECTOR-W/SHLD WASHER	98661-H1000	ALL
CONNECTOR-ELBOW W/SHLD WASHER	98662-H1000	ALL
GROMMET-WASHER HOSE	98893-24000	ALL
HOSE	9J700-31000	ALL
HOSE	9J700-31000	ALL
HOSE	9J700-31000	ALL