



Article	Part No.	Description
BOLT-WASHER ASSY	11233-06123	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	11400-08103	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	11403-08251	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	11403-08253	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT-FLANGE	11404-10403	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	11404-10653	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
NUT	13100-08003	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
WASHER-SPRING	13602-08003	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
STRAP	17993-10000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	42115-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT-SPECIAL	42121-21740	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GASKET	45244-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GEAR ASSY-PLANETARY INTERNAL	43921-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
ATA & TQ/CONV ASSY	45000-H1151	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45000-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CONVERTER ASSY-TORQUE	45100-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
HOUSING-CONVERTER	45259-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING	45219-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45221-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
LEVER-ATM MANUAL CONTROL	45223-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45223-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPACER	45228-4A000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45228-4A010	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CASE & BUSHING ASSY-ATA	45211-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45238-4A000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
COVER-PLATE	45242-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD

SCREW-CONUTERSUNK	45243-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GEAR-PUMP DRIVE	45249-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45246-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45247-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45248-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GEAR-OIL PUMP DRIVEN	45256-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45257-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45259-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45258-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SHAFT-MANUAL VALVE LEVER	45261-11710	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45261-4A000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PIN-SPRING	45263-11710	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SENSOR-TEMP	45263-H1070	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45263-H1155	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SEAL-OIL LIP	45264-11701	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CONNECTOR-OIL COOLER	45266-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45267-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
HOSE-BREATHER	45268-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SCREW	45269-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
ADAPTOR-BREATHER	45269-4A125	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
ADAPTOR-BREATHER	45260-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CLIP-HOSE	45278-4B200	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SUPPORT ASSY-STATOR	45281-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GASKET-OIL PAN	45751-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45288-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45289-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
COVER-CONNECTOR	45290-H1155	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
WASHER-WAVE	45291-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45311-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45311-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45313-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BEARING	45314-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SHAFT ASSY-INPUT	45316-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING ASSY	45386-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45332-11750	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45332-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON SUB ASSY-FWRD CLUTCH	45334-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-SNAP	45335-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH	45338-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH	45374-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH	45339-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH	45388-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45341-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING ASSY-CLUTCH PISTON	45341-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
HUB-FORWARD CLUTCH	45346-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45342-4A030	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45343-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
HUB-DIRECT CLUTCH INPUT	45344-33730	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45345-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45345-43550	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD

DISC-CLUTCH & FACING	45345-4B010	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45348-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45351-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH	45351-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45351-H1151	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BEARING	45352-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45353-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON & BALL-DIRECT CLUTCH	45355-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING ASSY-CLUTCH PISTON	45364-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING-DIRECT CLUTCH	45369-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH & FACING	45369-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
FLANGE-OVER DRIVE BRAKE	45377-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH & FACING	45378-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SUPPORT & BUSHING ASSY-CTR	45382-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON ASSY-CLUTCH	45381-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON-BRAKE	45384-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON-BRAKE	45384-11750	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING ASSY	45385-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-SNAP LOW & REVERSE BRAKE	45387-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-SEAL	45391-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH & FACING	45395-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45396-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
FLANGE-BRACKET	45396-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
FLANGE-DIRECT CLUTCH	45371-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45373-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45372-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CLUTCH ASSY-ONE WAY	45415-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GEAR & BUSHING ASSY-PLANETARY	45421-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-SEAL	45423-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45424-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH	45441-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
FLANGE-BRAKE	45444-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45446-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45442-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45443-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45445-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PLATE-RACE & REACTING INR	45443-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PLATE-CLUTCH BACKING	45445-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISK CLUTCH-NO.3	45447-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
WASHER-THRUST	45471-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45473-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45473-4A030	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
WASHER-THRUST	45474-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45474-4A030	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
WASHER-THRUST	45475-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GEAR-PLANETARY INTERNAL	45476-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GEAR SUB ASSY-FR PLANETRYL	45476-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45477-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45477-4A030	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GEAR-PLANETARY SUN FR	45478-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD

CARRIER & GEAR-PLANETARY RR	45480-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SHAFT & SLEEVE-INTERMEDIATE	45491-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GEAR-PLANETARY INTERNAL RR	45494-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE & BEARING ASSY-THRUST	45495-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45497-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON	45523-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SLEEVE-REACTION	45525-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON	45528-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
TUBE-BRAKE APPLY	45529-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
KEY-SYNCHRONIZER	45834-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
ADAPTOR SUB ASSY-T/M CASE	45543-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SEAL-OIL	45554-H1070	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45554-4A125	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45554-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GASKET-EXTENSION HOUSING	45553-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45583-11710	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRAG-PARK	45584-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SENSOR-SPEED	45584-H1070	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SENSOR-SPEED	45589-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PIN-PARK PAWL PIVOT	45585-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-SNAP	45586-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING-PARK PAWL TORSION	45587-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
ROD ASSY-ACTUATING PARK PAWL	45590-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PLATE-CAM	45596-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
STRAINER ASSY-OIL	45924-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
TUBE-O/D BRAKE APPLY	45861-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45689-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BALL-CHECK	45710-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING-2ND SPEED BRAKE ACCUM	45282-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON-2ND SPEED BRAKE ACCUMULADOR	45862-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45726-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45728-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON-FORWARD CLUTCH ACCUM	45735-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
MAGNET	45739-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PAN ASSY-OIL	45240-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45752-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PLUG	45753-4A060	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45753-H1070	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45755-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PLUG	45756-11710	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
LEVER-T/M CONTROL SHAFT	45264-H1070	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
WASHER-SPRING	45759-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BACKET-HARNESS CONNECTOR	45760-H1070	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
NUT	45761-11700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
ROTOR-SENSOR	45829-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CLUTCH-ONE WAY	45472-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45804-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45805-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-SEAL	45806-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SHAFT ASSY-OUTPUT	45752-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD

BALL-CHECK	45825-4A030	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RETAINER	45831-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CLUTCH ASSY-OD MULTI DISK	45890-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SWITCH ASSY-NEUTRAL START	45895-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
WIRE-TRANSMISSION	45896-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45247-H1155	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CARRIER-OVERDRIVE INPUT SHAFT	45927-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
WASHER-THRUST	45904-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-ONE WAY CLUTCH OTR	45905-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CLUTCH ASSY-ONE WAY	45906-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RETAINER-ONE WAY CLUTCH	45907-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45908-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON	45911-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING	45912-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING	45912-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH	45914-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45914-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45914-33702	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
HUB-OVERDRIVE BRAKE	45917-33702	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45918-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45919-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BEARING-THRUST	45920-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
WASHER-THRUST	45922-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45923-33701	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45924-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45951-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RACE-THRUST BEARING	45952-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTON-BRAKE	45925-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45926-33701	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
OD CARRIER & FO OWC ASSY	45926-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45927-33701	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-RETAINER	45929-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC-CLUTCH	45937-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45935-4B000	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
RING-SEAL	45932-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
DISC -CLUTCH NO.3	45933-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
CASE-OVERDRIVE	45931-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING-ATA CASE	45937-33700	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45953-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45953-H1155	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45955-H1155	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45955-4A125	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
O-RING	45955-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT	45965-4A030	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING-COMPRESSION	46248-H1155	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING-2ND	45982-H1155	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
SPRING-DIRECT CLUTCH ACCUMULAT	45983-H1155	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	45983-H1156	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PUMP ASSY-OIL	45271-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BODY ASSY-ATA VALVE W/SOL	46202-H1151	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD

	46202-H1150	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
BOLT-W/WASHER	46310-H1155	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
TUBE ASSY-OIL FILLER	46501-H1011	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
	46501-H1010	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
GAUGE ASSY-OIL LEVEL	46510-H1100	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD
PISTIN	45863-43500	D4BH(4D56 TCI), T/C INTER COOLER, 4 SPEED AT 4WD